



IMPORTANT NOTICE

For the installation of the MMD reverse gear, the following is required.

- * Loctite red
- * Loctite blue
- * For the milling procedure, air tools are a must.

Do not attempt without air tools!!

*In some cases, the slinger diameter might have to be reduced for smooth operation.

* Do not attach the relay directly to the motorcycle frame; find a wiring loom to attach it to.